

DEVICE INSTRUCTIONS

HS 051 / 0.5-1ML



Before use

- This product should only be used after being filled with oil.
- Before use, remove the mouthpiece plug and bottom silicone plug. The device will power on after removing the bottom silicone plug.
- When the silicone plug is inserted back, the bottom blue light will flash 4 times and the device will power off.

Power On/Off

- When the device is powered on, press the button 5 times within 3 seconds. The bottom red light will flash 3 times and the device will enter power-off mode.
- When the device is powered off, press the button 5 times within 3 seconds. The bottom blue light will flash 3 times and the device will enter power-on mode.
- The device cannot be used when powered off. It can only be powered on or charged.
- Removing or inserting the bottom silicone plug can switch the device between power-on and power-off modes.

Heating

- Inhale from the mouthpiece or press and hold the button to activate heating mode. The bottom blue light will gradually brighten and stay on as an indicator.
- When inhalation stops or the button is released, heating mode exits.

Preheating

- Press the button twice within 2 seconds to activate preheating. The preheating duration is 6 seconds. The bottom blue light will pulse as an indicator.
- During preheating, pressing the button once or inhaling from the mouthpiece will exit preheating mode.

Charging

- When the battery level is too low, the device will not work. The bottom red light will flash 8 times to signal the need to charge before further use.
- Charge the product via the Type-C port. The bottom blue light will pulse while charging.
- If the charger is disconnected during charging, the bottom blue light turns off and the device enters sleep mode.
- When fully charged, the bottom blue light turns off.

- The device remains powered on throughout the charging process.

Overtime Protection

- If inhalation or pressing the button lasts longer than 6 seconds, the device will stop outputting, and the bottom red light will flash 5 times as a warning.
- The device can be used again after the warning.

FILLING INSTRUCTIONS



HS 051 / 0.5-1ML

Fill the oil

- Unpack the device and keep it vertically upright within the tray.
- The oil tank has a capacity of ☐0.5ml ☐1ml, not in gram. **Make sure not to overfill.**
- -The oil tank has two oil filling holes. Fill only one outer hole and leave the other open for ventilation. **DO NOT fill the center airway hole.**
- Use a needle with a diameter of ≤ 1.6 mm. Insert the needle through the tank's silicone layer, but do not exceed 2/3 of the tank depth. DO NOT allow the needle to touch the bottom of the oil tank.
- The oil temperature must be below 176°F (80°C).
- Within 2 minutes after filling the device, make sure to press the mouthpiece down until it is fully seated.

Caution

- Failure to install the mouthpiece properly within 2 minutes after filling may result in leakage.
- Use a proper fixture or tool specifically designed to seat the mouthpiece. DO NOT use a hammer or mallet.
- Once the mouthpiece is fully seated, it cannot be removed without damaging the device.
- After filling, store or transport the device at a temperature below 95°F (35°C).

